

Model:		
Serial Number:		
Notes:		


## **Upper Casing Section**

- 1 Hot Water Basin
- 2 XF Spray Nozzles
- 3 BACross III® Upper Fill with Integral Drift Eliminators
- 4 Axial Fan Assembly (see detailed view)
- 5 Fan Guard Assembly
- 6 Fan Cylinder
- 7 FRP Casing Panels

#### **Lower Pan Section**

- 8 BACross III® Lower Fill with Integral Drift Eliminators
- 9 Make-up Valve Assembly
- 10 Float Ball
- 11 Pan Strainer
- 12 Pan Strainer Hood
- 13 Internal Walkway
- 14 Access Door

Series 3000 Cooling Tower



Reduce Downtime
Spare Parts List (page 2)

# **Recommended Spare Parts**

**BAC Factory Authorized Parts** are manufactured to meet rigorous specifications and are guaranteed to fit your unit and perform as original equipment.

BAC Factory Authorized Parts can be ordered through your local BAC Representative. Most BAC Representatives maintain a local inventory of commonly used parts. For a free unit inspection and a specific parts list for your serial number, contact your local BAC Representative today.

Even with BAC's fast delivery capability, it is still recommended that certain essential and emergency repair part be maintained in your inventory to minimize any potential downtime.



Find my BAC Rep to order parts, get maintenance tips, and get a free unit inspection: www.baltimoreaircoil.com/RepFinder



# Series 3000 Cooling Tower

**Belt Drive Configuration** 

### **Basic Recommended Spare Parts**

Basin Heater & LWCO (if equipped)

**Bearings** 

Bearing Greaser Refill (if equipped)

**Belts** 

Basin Heater & LWCO (if equipped)

Float Valve Kit & Float Ball

Solenoid Valve (if unit is equipped with EWLC option)

**Spray Nozzles** 

**Suction Strainer** 

Inlet Strainer (if equipped)

# Parts to Consider for Critical Applications

**Prop Fans with Bushings** 

**Fan Shaft** 

**Sheave and Bushings** 

**Fan Motor** 



