



PARTS MAP

Model: _____

Serial Number: _____

Notes:

Upper Casing Section

- 1 Factory Pre-Assembled Platforms with Perimeter Handrails
- 2 Drift Eliminators
- 3 BranchLok™ Removal System
 - A Feed Box Assembly
 - B Spray Branch
 - C Nozzles
- 4 Coil

Basin Section

- 5 Access Door with Safety Handle and Step
- 6 Internal Walkway
- 7 Fan Cover
- 8 Water Guards
- 9 Pump
- 10 Pump Riser Piping
- 11 Make-Up Valve Assembly
- 12 Float Ball
- 13 Strainer Assembly
- 14 EC Direct Drive Fan System Assembly
- 15 Terminal Box

VERTEX™ EVAPORATIVE CONDENSER

EC Direct Drive System



Reduce Downtime
Spare Parts List (page 2)

Recommended Spare Parts

BAC Factory Authorized Parts are manufactured to meet rigorous specifications and are guaranteed to fit your unit and perform as original equipment.

BAC Factory Authorized Parts can be ordered through your local BAC Representative. Most BAC Representatives maintain a local inventory of commonly used parts. For a free unit inspection and a specific parts list for your serial number, contact your local BAC Representative today.

Even with BAC's fast delivery capability, it is still recommended that certain essential and emergency repair part be maintained in your inventory to minimize any potential downtime.



Find my BAC Rep to order parts, get maintenance tips, and get a free unit inspection: www.baltimoreaircoil.com/RepFinder



Vertex™ Evaporative Condenser

EC Direct Drive System

Basic Recommended Spare Parts

- Basin Heater & LWCO** (if equipped)
- Door Gaskets**
- Make-Up Valve Assembly & Float Ball**
- Spray Nozzles**
- Suction Strainer**
- Pump Seal Kit**

Parts to Consider if Extended Downtime is a Concern

- EC Direct Drive Fan System Assembly**
- Pump**



Scan to locate your local BAC Representative